

KEY POLYMER **SLIPSTOP** Traction Additive for Key Floor Restore

KEEP YOUR DRIVERS ON THEIR FEET!

APPLICATION INSTRUCTIONS

KEY SLIPSTOP IS BLENDED INTO A KEY FLOOR RESTORE APPLICATION

- 1 Following instructions in the KEY FLOOR RESTORE KIT, pour 1 Part B container into a Part A container.
- 2 Add 1 container of KEY SLIPSTOP to FLOOR RESTORE.
- 3 Mix for 5 minutes with stir stick provided and begin to apply FLOOR RESTORE as indicated in instructions.
- 4 Before every pour of FLOOR RESTORE mixture, do a quick re-stir to ensure even distribution, as SLIPSTOP will tend to settle in the mix.
- 5 After first batch of FLOOR RESTORE has been applied, mix second batch of Parts A & B with the other container of SLIPSTOP. Stir and complete the application.



For additional safety information refer to
Safety Data Sheets on our website
KeyTransportationProducts.com.



KEY POLYMER
CORPORATION

17 SHEPARD ST., LAWRENCE, MA 01843
978.683.9411 • Fax: 978.686.7729
WWW.KEYTRANSPORTATIONPRODUCTS.COM

DCO 4770

WWW.KEYTRANSPORTATIONPRODUCTS.COM