

TOUGH-SEAL™ TRP

SlipStop

A Key Polymer Product

APPLICATION INSTRUCTIONS

KEY SLIP STOP IS INTENDED TO BE USED WITH A KEY FLOOR RESTORE KIT

- 1 Follow the mixing instructions in the KEY FLOOR RESTORE KIT. (Mix only one set at a time!) But before stirring add a complete container of KEY SLIP STOP before mixing the KEY FLOOR RESTORE.
- 2 Mix for 5 minutes with the stick provided and continue to follow the KEY FLOOR RESTORE instructions.
- 3 Re-Stir each time you pour additional material onto the trailer floor to assure even distribution.



For additional safety information refer to Safety Data Sheets on our website keypolymer.com.



A Key Polymer Product

KEY POLYMER



17 Shepard Street • Lawrence, MA 01843
978-683-9411 • www.keypolymer.com

KEYFLOORRESTORE.COM